

Mounting instruction PRO-Grip SF



1. Recommended tools and safety equipment:



2. Open pin connectors before fitting



3. Prepare chain to be driven on



4. Drive forward, pulling the chain into place



5. Check the center of the chain pattern follows the centre of the tire pattern.



6. Use the Olofsfors installation tool to pull the ends together



7. Connect the mesh. Use the additional links enclosed if necessary. Usually it's easiest to connect the outer part of the tag chain first



8. Always connect the side chains after the tag chain



9. The need for the enclosed extra links will vary with tire wear and brand



10. Adjust the side chains if necessary

