

# CoverX-M track tensioner



1. Pull track on by using chain or lashing belt.



2. Put U clamps in place.



3. Leave joint behind bogie center line.



4. CoverX M tensioner tools.



5. Place first pulling plate according picture and add securing plate.



6. Place second pulling plate and add securing plate.



7a. Put tensioner hook to first pulling plate.



**7b.** Put the other tensioner hook to second pulling plate.



**8.** Ensure the pulling plates are well at middle of track. Place the ratchet and make pre-tensioning.



**9.** Make sure the pulling plates are firmly in tensioner hooks before actual tensioning!

Take the U clamp away at start of tensioning.



**10.** You can drive the machine back and forth about 10-20cm during the tensioning process, to help the tensioning.



**11.** Place track locks and remove the tensioner tools.



**12.** Done!