


TRACKS SHORTENING INSTRUCTIONS

To always insure that your Eco-Tracks have the right tensiity, we provide an easy solution to shorten your tracks. Natural wear will cause any bogie tracks to loosen, however shortening the tracks will increase the lifespan and capacity of your product.

Max 50 mm



↑
Small track lock




↑
Medium track lock




↑
Large track lock

Example 294-644421 EVO-Soft 710 x 26.5"


STEP 1




STEP 2



STEP 3



STEP 4



IF FURTHER SHORTENING IS REQUIRED REPEAT STEP 1-4

